

Holme County Fair Antique Tractor pull rules

Class A 1900–1958 3,800 lbs. max. 5 mph

Class B 1900–1958 4,500 lbs. max. 5 mph

Class C 1900–1958 5,500 lbs. max. 5 mph

Class D 1900–1958 6,500 lbs. max. 5 mph

Class E Farm Stock 8,000 lbs. max. 6 mph

1. 20" drawbar maximum height
2. 18" minimum length drawbar from center of axle.
3. Each tractor must furnish a horizontal flat plate with a minimum of 3" x 4" hole. A clevis can be used, but drawbar height will be measured at point where clevis attaches to tractor.
4. Front weights may not extend more than 11' from center rear axle of tractor.
5. Rear weights cannot extend beyond 12" of rear tire.
6. Speed will be monitored by a speed measuring device or a pace tractor.
7. Stock block, crankshaft and cylinder head required. Replacement update from manufacturer or parts supplier accepted.
8. Gas tractors must have the stock carburetor, or its replacement as supplied by original manufacturer. No overhang of carburetor to manifold.
9. Diesel tractors must have a stock fuel pump or its replacement as supplied by original manufacturer.
10. No blowers or turbos.
11. No cut or ground tires.
12. No homemade tractors.
13. Pump gas, propane or diesel (sold as off road diesel only) and available to general public. No alcohol or nitrous oxide.
14. One false start within 75 feet allowed.
15. Only stock appearing manifolds are allowed. Dual exhaust not allowed except after stock manifold.
16. Any tractor can qualify in a maximum of two classes. One hook per class.

17. Wheelie bars are highly recommended.
18. Maximum tire size 18.4 x 38. No radial tires allowed. SEE EXHIBITOR'S RULES & REGULATIONS – PAGE 5 LOUDONVILLE POWER PULL, CONT. DEPT. 9
19. 19. Kill switch recommended.
20. Helmets required under 16 years of age.
21. Farm Stock Class E has no tractor age restriction; turbos and radial tires allowed. All other antique tractor rules apply